# **Benefits & Features**

Veritas Global Exotic Plans

### Emergency Roadside Assistance

We pay for the cost of emergency roadside services, including:

- Towing
- Battery Jumpstarts
- Flat Tire Changes Lockout Assistance
- Fuel Delivery (You are responsible for fuel costs)

### **Rental Car Coverage**

We pay for the expense of a rental car when your vehicle's failure is approved for repair.

### Trip Interruption Benefits

In the event you experience a breakdown 150 kilometers away from your home, we will pay for a portion of your meals and lodging for covered repairs.

### **Global Protection**

All of our plans can be used across Canada and the United States, so if you are traveling and experience a breakdown, you can rest assured your plan will be accepted.

### Transferable Coverage

If you sell your car, you can transfer the coverage to the new owner, which increases the value of your vehicle!

\* Please view each contract for full details on coverage of each plan.

All coverage options come with free 24 hour roadside assistance, towing, and a rental car program.



# **Costs WITHOUT Veritas**

Engine	
\$20,151	
Drive Axle	
\$3,622	

A/C Repair **Transmission** \$2.958 \$9.393 **Front End Repair** \$3,622

# Cars have problems.

Everyone has insurance on their vehicles to protect them in the event of an accident. However, many people who have collision insurance never even use it. Unfortunately, it is inevitable that nearly everyone will eventually experience a mechanical breakdown. Veritas Global Protection Plans provide you with a financially savvy alternative to paying for the potentially enormous costs of a major or minor repair.

A mechanical breakdown can be very stressful not only costing you money, but significant time. This is why all of our plans also include emergency roadside assistance, towing, and travel interruption coverage.

With a Veritas Global protection plan, you have someone to call if you are ever stranded by a breakdown. We will put you in a rental car and most importantly, cover the cost of your repairs to get you back on the road. We provide you peace of mind, knowing your vehicle is covered by an experienced company, focused on giving you with the best customer service in the industry!

As an exotic car driver, you know that the cost to fix an engine, transmission, or other component can be astronomical! You've worked hard for your exotic car - now let us protect it!

### **Veritas Global Protection Services, INC**

60 Atlantic Avenue, Suite 200 Toronto, ON M6k 1X9

(888) 222-3020 | wwww.veritasglobalprotection.ca

EXOCF71CAD

Rev. 120119



# **EXOTIC** PLANS

Peace of Mind, Worldwide veritasglobalprotection.ca/exotic

# **EXOTIC** PLANS Levels of Coverage.

Our **Veritas Global Exotic** program is designed to provide you with options when selecting coverage for your vehicle. Our Exotic Program comes with three different levels of coverage, allowing you to choose the level and cost that best suits you. With Veritas Global, no matter which level of coverage you choose, you can have peace of mind knowing the major components of your vehicle are protected!



### Preferred

Preferred provides protection for the powertrain and selection of components that are the most likely to fail.

# 🚺 Deluxe

Deluxe coverage covers most major components of your vehicle. Along with everything in the Preferred Plan, Deluxe includes coverage of your Fuel System, Suspension, and an Enhanced list of Electrical components.

## Premier

list of exclusions.

Our best coverage. Veritas Global Premier is the most comprehensive plan available. It covers nearly every mechanical and electrical component of your vehicle except for a small

All of our plans are accepted at nearly any dealership or repair facility in Canada or the United States



# Compare Coverage Levels →

Refer to our comparison chart on right to find the best Veritas Global Exotic Plan for your vehicle.

### engine

Oil Pump, Timing Drive Gears, Camshaft, Valve Train, Crankshaft, Connecting Rods, Intake and Exhaust Manifolds, Timing Gear Cover, Flywheel, Oil Pump Housing, Harmonic Balancer, Valve Covers, Oil Pan. All internal, Lubricated Parts of the Engine. The Cylinder Block and Cylinder Heads are covered only if damaged by the Failure of an internal, Lubricated Part of the Engine.

### turbo / supercharger (factory installed only)

All internal, Lubricated Parts of the Turbocharger / Supercharger. The Housing is covered only if damaged by the Failure of an internal, Lubricated Part.

### transmission / transaxle

Torque Converter, Torque Converter Housing, Vacuum Modulator, and all internal, Lubricated Parts of the Transmission or Transaxle. The Transmission/ Transaxle Housing is covered only if damaged by the Failure of an internal, Lubricated Part of the Transmission/Transaxle.

### differential / driveline

Universal Joints, CV Joints, Propeller Shafts, Drive Shaft, Drive Shaft Yokes, Driver Shaft Carrier, Axle Shafts, Front Hubs, Locking Hubs. All internal, Lubricated Parts of the Differential. The Differential Housing is covered only if damaged by the Failure of an internal, Lubricated Part of the Differential.

### transfer case

All internal, Lubricated Parts of the Transfer Case or All-Wheel Drive Mechanism. The Transfer Case Housing or Housing for the All-Wheel Drive Mechanism is covered only if damaged by the Failure of an internal, Lubricated Part.

### electrical

Deluxe and Premier cover: Electronic Ignition Module, Distributor, Washer Pump, Cruise Control Module, Heater Blower Motor, Power Antenna Motor, Electronic Door Lock Actuators, Electronic Trunk Lock Actuators, Electron-ic Instrument Clusters. All Coverage levels: Starter Motor and Solenoid, Starter Relay, Alternator, Voltage Regulator, Front and Rear Windshield Wiper Motors, Power Window Switches. BRAKE: Master Cylinder, Calipers, Combination Valve, Wheel Cylinders.

### brake system

Deluxe and Premier cover: Assist Booster, Metal Lines, Řetainers. All Coverage levels: Electronic Control Processor, Pressure Modulator Valve, Isolation Dump Valve, Wheel Speed Sensors, Hydraulic Pump/Motor Assembly, Accumulator.

### steering

Steering Box, Steering Rack & Pinion, Power Steering Pump, Power Steering Cooler.

### cooling system

Deluxe and Premier cover: Radiator Sensor, Temperature Sensor. All Coverage levels: Water Pump, Radiator Fan, Electric Radia-tor Fan Motor.

### air conditioning

Deluxe and Premier cover: Evaporator, Expansion Valve, Orifice Tube, Compressor Clutch. All Coverage levels: Compressor, Condenser, Receiver Drier, Accumulator.

### fuel system

Fuel Pump, Throttle Body Assembly, Injection Pump, Metal Lines, Vacuum Pump.

### suspension

Upper and Lower Control Arms and Shafts, Upper and Lower Ball Joints, Spindles, Spindle Supports, Coil Springs, Leaf Springs, Stabilizer Shafts.

### **exclusionary** Seals and gaskets are covered in connection with the replacement of a covered component.

seals and gaskets Available as an add-on option for any coverage level.

