



## Benefits & Features

### Veritas Global Select Plans

#### ✓ Emergency Roadside Assistance

We pay for the cost of emergency roadside services, including:

- Towing
- Battery Jump Starts
- Flat Tire Changes
- Lockout Assistance
- Fuel Delivery (You are responsible for fuel costs)

#### ✓ Rental Car Coverage

We pay for the expense of a rental car when your vehicle's failure is approved for repair.

#### ✓ Trip Interruption Benefits

In the event you experience a breakdown 150 kilometers away from your home, we will pay for a portion of your meals and lodging for covered repairs.

#### ✓ Global Protection

All of our plans can be used across Canada and the United States, so if you are traveling and experience a breakdown, you can rest assured your plan will be accepted.

#### ✓ Transferable Coverage

If you sell your car, you can transfer the coverage to the new owner, which increases the value of your vehicle!

*\* Please view each contract for full details on coverage of each plan.*

**All coverage options come with free 24 hour roadside assistance, towing, and a rental car program.**



## Costs *WITHOUT* Veritas

Engine	A/C Repair	Transmission
\$9,186	\$1,540	\$4,888
Drive Axle	Front End Repair	
\$1,885	\$1,126	

## Cars have problems.

Everyone has insurance on their vehicles to protect them in the event of an accident. However, many people who have collision insurance never use it. On the other hand, nearly every vehicle will require repairs due to mechanical failure. An average engine costs **\$9,186** to repair and the average transmission costs **\$4,888**. While these represent the major components, minor parts can still cost anywhere from **\$300** to **\$3,000**.

The question you need to ask is simple: **do you want to pay for these huge repair costs or would you rather someone else pay it for you?** With a Veritas vehicle protection plan, we pay the costs so you don't have to. In many situations, the cost of a single covered repair pays for the entire protection plan!

A mechanical breakdown can be very stressful, not only costing you money, but time. This is why **all our protection plans come with emergency roadside assistance, first day rental car benefits, and travel interruption coverage included at no extra cost.**

With a Veritas Global protection plan, you have someone to call if you are ever stranded by a breakdown. We will put you in a rental car and most importantly, cover the cost of your repairs to get you back on the road. We provide you peace of mind, knowing your vehicle is covered by an experienced company, focused on giving you with the best customer service in the industry.

**All of our plans are accepted at nearly any dealership or repair facility throughout Canada.**

*\*Please see your contract for details*

### Veritas Global Protection Services, INC

60 Atlantic Avenue, Suite 200  
Toronto, ON M6K 1X9

(888) 222-3020 | [www.veritasglobalprotection.ca](http://www.veritasglobalprotection.ca)

SEL24CD1


Rev. 090124



# Veritas

Global Protection

## SELECT PLANS



Peace of Mind, Worldwide  
[veritasglobalprotection.ca/select](http://veritasglobalprotection.ca/select)

# SELECT PLANS

## Levels of Coverage.



### Powertrain

Covers the most expensive components on your vehicle including: basic powertrain coverage for the Engine (Gas or Diesel), Turbo/Supercharger, Transmission (Automatic or Standard), Transfer Unit (4 x 4), and Drive Axles (Front or Rear).



### Preferred

This includes all of the Veritas Select Powertrain coverage plus the components that fail the most frequently, including: Steering (Manual or Power), Basic Electrical, Front Suspension, Brakes, Basic Air Conditioning, and Basic Exterior.



### Deluxe

Coverage includes all components covered by Powertrain and Preferred along with increased coverage for the Powertrain, Electrical, Front & Rear Suspension, Anti-Lock Brakes (ABS), Air Conditioning, Cooling, Fuel Delivery, and Additional Interior/Exterior components.



### Premier

Our best level of coverage! Veritas Select Premier protection plans cover nearly every mechanical component on your vehicle. The items not covered are listed in the exclusions section of your contract. Common maintenance items such as brake pads and oil changes are excluded from coverage. See your contract for full details.

**\* Please see your contract for a full list of coverage details and exclusion**

## Compare Coverage Levels →

Refer to our comparison chart on right to find the best Veritas Select Plan for your vehicle.

**engine**  
**All levels cover:** All internally lubricated engine parts including: pistons, piston rings, piston pins, crankshaft and main bearings, connecting rods and bearings, camshaft and bearings, timing chain or belt, timing gears, tensioners/guides, intake and exhaust valves, valve springs, valve guides, oil pump and oil pump housing, push rods, rocker arms, rocker arm shafts, hydraulic and solid lifters, intake & exhaust manifold, distributor shaft and housing, harmonic balancer, metal valve covers, timing gear cover, air filter and housing, water pump, fuel pump, vacuum pump, thermostatically controlled air intake, oil pan, engine block and heads are covered if damaged by the Failure of an internally lubricated moving part.

**transmission/transaxle**  
**All levels cover:** All internal parts; torque converter, vacuum modulator, mounts, covers, pans and cases are covered if damaged by the Failure of an internally lubricated moving part. Note: No Coverage is afforded for clutch assembly, pressure plate, flywheel, throw out bearing, worn synchronizers or cables.

**transfer case**  
**All levels cover:** All internal parts; transfer case is covered if damaged by the Failure of an internally lubricated moving part.

**drive axles**  
**All levels cover:** All internal parts; "U" joints, propeller shafts, CV/tripod joints, differential case is covered if damaged by the failure of an internally lubricated moving part.

**turbo / supercharger (factory only)**  
**All levels cover:** All internal parts; housing is covered if damaged by the failure of an internally lubricated moving part.

**air conditioning / heating system**  
**Preferred covers:** Compressor, internal assembly including pistons, rods, bearings, valves and shafts, clutch, coil and pulley, orifice tube, condenser, evaporator, manual switches.  
**Premier and Deluxe cover:** All components covered by Preferred along with the expansion valve, dryer tank, accumulator, POA valve, hi/low pressure cut-off switch, ducts and outlet hoses, automatic temperature control programmer.

**suspension**  
**Preferred covers:** Upper and lower control arms, control arm shafts and bushings, upper and lower ball joints, steering knuckles, stabilizer shaft, link and bushings, kingpins and bushings, strut bar and bushings, spindles and spindle supports.  
**Premier and Deluxe cover:** All components covered by Preferred along with MacPherson struts, shackles, bushings and eye bushings, springs, torsion bars and bushings, stabilizer linkage and bushings, wheel bearings and seals, automatic leveling unit compressor, sensor and limiter valve.

**steering**  
**Preferred covers:** All internal parts in rack and pinion, all internal parts in recirculating ball housing, couplings, gear housing, power steering pump, steering main and intermediate shafts, power cylinder assembly, power steering cooler, control valve, Pitman arm, idler arm, tie rod ends, drag link/center link.  
**Premier and Deluxe cover:** All components covered by Preferred along with the control unit, actuator, mode selector, position sensor, rear tie rod assembly, rear gear assembly, cylinder barrel, center joint, pinion; power steering housing is covered if damaged by the failure of an internal part.

**cooling system**  
**Premier and Deluxe cover:** Radiator, fan clutch and fan, engine cooling fan motors, heater core, engine cooling fan and motor, fan clutch, belt tensioner, radiator, heater core, thermostat, blower motor, hot water valve, engine oil cooler, cooler lines and fittings.

**fuel system**  
**Preferred covers:** Fuel pump, fuel injection pump, metal fuel lines, fuel pressure regulator, fuel sending unit, and fuel gauge.  
**Premier and Deluxe cover:** All components covered by Preferred along with the fuel injector metering pump, fuel injectors, fuel distributor, diesel injection pump, fuel tank, metal fuel lines.

**brake system**  
**Preferred covers:** Master cylinder, power assist booster and valve, wheel cylinders, calipers, combination valve, steel lines and fittings, backing plates, vacuum assist booster pump, springs, clips and retainers, self-adjusters, rear activators, parking brake linkage and cables.  
**Premier and Deluxe cover:** All components covered by Preferred along with the ABS Unit, electronic control unit, anti-lock computer module, wheel speed sensors/exciters, proportioning valves, high pressure hydraulic pump, electro-hydraulic proportioning control valves, accumulator.

**electrical**  
**Preferred covers:** Anti-detonation/knock sensor, ESC/EEC/ECM module, electronic module retard vacuum switch, electronic ignition module, igniter, electronic digital instrument cluster, digital driver information display and module, instrument panel printed circuit board. Alternator, voltage regulator, starter motor, drive and solenoid, power seat motors, power window motors, regulators and drives, front wiper motor including circuit board, relay and delay switch, manually operated switches for power windows, power seat(s), turn signal switch, headlamps, wipers (front and rear), emergency warning flashers, horn button, power door lock actuators, trunk actuator.  
**Premier and Deluxe cover:** All components covered by Preferred along with the fuel gauge sending unit, heated back glass elements (glass is not covered), rear wiper motor, heater blower motor, horn, factory installed sun/moon roof motor and its wiring harness and switches, convertible top motor and switches, power antenna motor, mast and switches, MAF/MAP sensor, EGR valve, DPFE valve, remote keyless entry transmitter and receiver, heated side view mirror element, cruise control servo, module and transducer, compass, speed sensor, thermometer.

**seals and gaskets**  
 Seals and gaskets, if needed, are covered for the following assemblies:  
**Powertrain covers the following assemblies:** Engine, Turbo/Supercharger, Transmission, Transfer Unit and Drive Axle(s)  
**Preferred covers the following assemblies:** Steering, Front Suspension, Brakes and Air Conditioning.  
**Deluxe covers the following assemblies:** Rear Suspension and Anti-Lock Brakes.  
**Premier covers:** All Seals & Gaskets not listed in Exclusions.

**exclusionary**  
 Exclusionary covers everything except a small list of excluded items.

	POWERTRAIN	PREFERRED	DELUXE	PREMIER
engine				
transmission/transaxle				
transfer case				
drive axles				
turbo / supercharger (factory only)				
air conditioning / heating system				
suspension				
steering				
cooling system				
fuel system				
brake system				
electrical				
seals and gaskets				
exclusionary				